



STEEDA

2021



Escape/Bronco Sport/Maverick Strut Tower Brace

Installation 555-5736

1. Remove the two factory strut bolts on the inside, closest to the engine on each of the strut towers.
2. Place the Steeda strut tower brace with the logo facing forward over the two bolt holes that you just removed.
3. Using the supplied bolts, washers, and aluminum spacers. Install the washer into bolt pocket of the brace, insert the bolt and use the aluminum washers to space the brace upwards for extra clearance.
4. Once the two M8 bolts are started, tighten them to the manufacturer specs with 23 ft.lb.
5. **Note:** Some models have a crankcase ventilator assembly that needs to be relocated from the intake manifold. Disconnect the vacuum line at the intake and pull up on the ventilator to remove it from the bracket. Use the provided zip ties to secure it out of the way.
6. **Note:** If you have a Hybrid version, please relocate the connector as shown.

