


## Cruise Control Module (CCM)



### Removal

**NOTE:** Removal steps in this procedure may contain installation details.

1. Remove the front bumper cover.  
Refer to: [Front Bumper Cover](#) (501-19 Bumpers, Removal and Installation).
2. Disconnect the CCM electrical connector.



3. Release the clip and remove the CCM from the bracket.



## Installation

1. To install, reverse the removal procedure.
2. **NOTE:** *This step is only necessary when installing a new component.*

Using a diagnostic scan tool, complete the PMI process for the CCM following the on-screen instructions.

3. Align the CCM.

Refer to: [Cruise Control Radar Alignment \(419-03A Cruise Control - Vehicles With: Adaptive Cruise Control, General Procedures\)](#).

© Copyright 2025, Ford Motor Company.